



Mobile Gaming Touchroller

© 2019 GameSir Inc. All rights reserved. Product may vary slightly from those pictures.

User Manual►

POWER UP YOUR GAMESIR DEVICE



https://gamesir.hk/pages/g-crux (GameSir G-Crux)

PACKAGE CONTENTS

GameSir G6/G6s Mobile Gaming Touchroller Micro-USB Cable User Manual

SYSTEM REQUIREMENT

iOS 9.0 or later

REGISTRATION


Register your GameSir ID online at https://gamesir.hk/ to get realtime information on your product's warranty status and a series of exclusive benefits from GameSir.

YOUR BENEFITS

* 12-month replacement of the same model from the date you received it.

* Contact us for free online technical support Website: https://genesi.rkk E-mail: cs@gamesi.rkk Hotline: +1-888-937-1733 (USA & Canada) Service Hours: Sat.-Sun. 9:00 AM-6:00 PM PST Mon.-Wed. 6:00 AM-3:00 PM PST Thur.-Fri. 6:00 AM-3:00 PM PST

DEVICE LAYOUT



G-Touch TECHNOLOGY

GameSir G6/G6s uses G-Touch technology that supports iOS native games. Download games from Apple App Store and you can play games after Bluetooth connection. Meanwhile, with the GameSir G-Crux app, you can customize buttons to your own preference to maximize in-game control.

CONNECTION

- a. Press the Y button and power button on GameSir G6 / G6s, the LED mode indicator light will flash in pink.
- b. Turn on Bluetooth on iOS device and connect to GameSir G6 / G6s. The pink LED mode indicator light will remain lit. The connection is complete.
- *You only need to press the power button the next time, GameSir G6/G6s will automatically connect to the iOS device.



AUTOMATIC POWER OFF

- a. When GameSir G6/G6s is connected, it will automatically turn off if there is no operation for 5 minutes.
- b. When GameSir G6/G6s is in a low battery state, the LED power indicator light will flash in red.
- c. GameSir G6/G6s will automatically turn off when the available battery power is lower than the battery protection requirement.

POWER INDICATOR

- a. When GameSir G6/G6s is being charged, the LED power indicator light will flash in red.
- b. When GameSir G6/G6s is fully charged, the blue LED power indicator light will stay on.

JOYSTICK CORRECTION

When GameSir Gel/Ges is turned on, press and hold L1+L2+C+L3 buttons simultaneously for 3 seconds, the LED mode indicator light and power indicator light will flash alternately, indicating that it is in the joystick correction mode. Rotate the joystick 3-5 turns, then press L1+L2+C+L3 buttons simultaneously for 3 seconds to save the correction. The joystick correction is complete.

DELETE PAIRING DATA

When GameSir G6/G6s is turned on, press and hold C+Z buttons simultaneously for 3 seconds, the LED mode indicator light will flash quickly, indicating that the pairing data is deleted, you can connect to a new iOS device.

DUAL MOTOR VIBRATION

Dual motor vibration enhances game immersion and you can customize the intensity and duration of vibration with GameSir G-Crux app.

Please note: Only GameSir G6s has dual motor vibration.

ehivo